



INSTALLATION - Surface Mount or Recessed

Recessed Installation

1. Remove mechanism from housing. Discard skirt.
2. Position housing so it will be flush with the finished wall. Nail housing to wall stud.
3. Bring wiring through access hole and connect wires to terminals shown.
4. Place mechanism into housing. Bend locking tabs inward with a screwdriver to hold mechanism in place.
5. Finish drywall.
6. Install grille by using the screws provided.
7. Turn on power. Make sure button(s) operate mechanism properly.



Three Door Chimes



Questions?

Visit www.craftmade.com or call Craftmade Technical Support at (800)-486-4892

CRAFTMADE™

ONE YEAR LIMITED WARRANTY

TERM: One year from date of purchase of the original consumer.

COVERAGE: Products will be free from defects in materials or workmanship. There are no other warranties, express or implied, including, but not limited to, implied warranties of merchantability or fitness for a particular purpose. Not covered: Normal maintenance and service, products subject to misuse, neglect, accident, improper maintenance or service, or installation differing from the recommended installation instructions.

REMEDY: Craftmade will repair or replace, at its option, without charge, any product or part, which is found to be defective under normal use. This is the sole remedy under this warranty. Craftmade will not be liable for secondary, consequential or special damages arising out of or in connection with product use or performance.

This warranty gives you specific legal rights, and you may have other rights, which vary by state. This warranty supersedes all prior warranties.

To qualify for warrant service, please contact Craftmade with the following information: model number, evidence of original purchase date and nature of defect.


CRAFTMADE

www.craftmade.com

1-800-486-4892

Door Chime Wiring

One Door Chime



Two Door Chimes

