

PUSHBUTTON INSTALL GUIDE

1. Install alkaline type A23 12 Volt Battery into push button. Remove push button back by pushing in the tab with a small screwdriver (see figure 1).

2. Mount push button. Use either screws (supplied) or double sided tape.

-To mount with screws, remove the back of the case and attach the case to the door jamb or wall as shown (see figure 1).

-If mounting with double sided tape make sure the door jamb is thoroughly cleaned before adhering.

Snap the front of the push button onto push button plate.




Fig. 1

WARNING:

This product uses alkaline batteries. To prevent possible injury or death:

- Keep batteries away from small children
- If a battery is swallowed, call a doctor immediately.

This device complies with Part 15 of the FCC rules and RSS-210 of Industry Canada. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment